MEYERTECH
SECURITY with VISION

Software Upgrade

ZoneVu

ZVK-007 Operator Keyboard

This document details the procedure for upgrading equipment firmware/software.



1. Unplug the ZVK-007.
2. If ZVK-007D, remove bottom of the box to gain access.
3. Locate ZVK-007 CPU Module EPROM.
4. Note Orientation of the EPROM, and replace with the upgrade, ensuring all pins are firmly in place.
5. Power up ZVK-007 whilst holding function key F4. Note that Defaults have been loaded by viewing the LCD during the power up sequence.
6. Replace cover.

N.B. After upgrading, the keyboard will have a default MAC (address) of 1. If there are several keyboards on the system, the MAC **must** be correctly reset.

EEPROM Label

K1GEN007 V4.05-139B

MEYERTECH LIMITED

OFFICE BLOCK ONE
SOUTH LINK BUSINESS PARK
OLDHAM OL4 1DE

TEL +44 (0) 161 628 8406
FAX +44 (0) 161 628 9811
Email sales@meyertech.co.uk
http://www.meyertech.co.uk